

HERE'S HOW YOU CAN GET EVERYTHING DONE.

1 Display screen

Your "window" into the world of interactive shopping and information services! The 8-line, 20-character screen shows easy-to-follow messages every step of the way.

2 Contrast setting

Press to select one of eight brightness levels for the illuminated display screen.

3 Softkeys

These six flexible and clearly labeled keys offer different service choices and take on different functions once you select a service. They also make it easy to handle regular phone calls and use the Vista 350's features.

4 Directional keys

These four arrow keys move you up/down and left/right through information on the display screen, and move the cursor when entering or deleting information.

5 Services

Press to see your "menu" of services. Pressing the appropriate softkey presents more information or connects you with the service.

6 Redial

Shows the last five numbers you dialed.

7 Callers

Shows the last 25 calls you received (with Call Display). Choose to see all incoming calls, only unanswered calls, or no calls. Dial callers back using Handsfree or the Dial softkey.

8 Print

Prints a copy of your Directory, Callers List or what's on the screen (when you're connected to a printer).

9 Directory

Stores up to 50 names and numbers you've entered or copied from the Callers List. Call any number by pressing the Dial softkey, or use Handsfree. Lock the Directory to prevent accidental deletion of entries.

11 Volume control

Adjusts the volume of the receiver, speakerphone or ringer.

12 Numeric keypad

Press to dial a number, make entries in your Directory, or alphabetically access a name stored in the Directory.

13 Handsfree/Mute indicator light

Lights up when you use Handsfree mode. Flashes rapidly and display shows *Microphone muted* when call is muted.

15 Indicator light

Flashes when the phone is ringing; display shows phone number (and name, if available; Call Display required). Flashes slowly when a message is waiting and display shows *Message waiting* (voice messaging service required).

16 Hold

Suspends your current call so you can go to another phone, talk in privacy or get something you need, without the worry of disconnecting your caller.

17 Link

When no onscreen option appears, lets you instantly switch between two calls or connect a third caller (requires Call Waiting or Three-Way Calling).

18 Goodbye

Ends a call, leaves the Directory or stops the call timer.

19 Options

Lets you customize your Vista 350 to your specific needs, including:

- setting Vista 350 feature prompt language (English or French)
- entering the time and date
- choosing one of three ring tones
- activating the call timer or live dial pad
- clearing the message-waiting screen prompt
- entering area codes
- selecting the answer mode for your Callers List (all calls, unanswered calls or no calls).

14 Handsfree/Mute

Switches back and forth between privacy mode (using the handset) and speakerphone mode (using the built-in microphone). Also lets you talk privately with someone in the room without your caller hearing.



Available colours: Charcoal/Oxford Gray, Almond/Oxford Gray; White/Oxford Gray

Vista and LINK are trademarks of Northern Telecom.